



PROFORM M GRAVEL STOP

WITH CONTINUOUS CLEAT

INSTALLATION INSTRUCTIONS

ENSURE THAT THE PROFORM M GRAVEL STOP SYSTEM AND MEMBRANE PLIES ARE CONFIGURED IN ACCORDANCE WITH SIPLAST STANDARD SPECIFICATIONS AND THE PROFORM M GRAVEL STOP DETAIL RELEVANT TO THE ROOF SYSTEM.

NOTE: INSTALL MITERS FIRST.

STEP ① INSTALL GRAVEL STOP MITERS FIRST. INSERT ONE SPLICE PLATE UNDER EACH END OF MITER WITH PS-715 NS ELASTOMERIC SEALANT TO BE FIELD APPLIED TO TOP OF EACH SPLICE AS SHOWN. SET DECK FLANGE IN SIPLAST MASTIC OR SEALANT. FASTEN WITH PROVIDED 1 1/4" RING SHANK ROOFING NAILS

PS-715 NS ELASTOMERIC SEALANT

① MITER

STEP ② POSITION 12'-0" CONTINUOUS CLEAT SECTIONS UNDER SPLICE PLATE AND MITER THEN FASTEN 12" O.C. AS SHOWN WITH PROVIDED 1 1/4" RING SHANK ROOFING NAILS. LAP CONTINUOUS CLEAT 1" AT JOINTS.

STEP ③ INSERT ONE SPLICE PLATE UNDER LEFT END OF 12'-0" GRAVEL STOP SECTION WITH PS-715 NS ELASTOMERIC SEALANT TO BE FIELD APPLIED TO TOP OF EACH SPLICE AS SHOWN.

STEP ④ INSTALL 12'-0" GRAVEL STOP SECTIONS WITH DECK FLANGE SET IN SIPLAST MASTIC OR SEALANT. HOOK DRIP EDGE OF EACH GRAVEL STOP SECTION ONTO CONTINUOUS CLEAT, ROTATE INTO PLACE, AND FASTEN IN STAGGERED HOLES 3" O.C. WITH PROVIDED 1 1/4" RING SHANK ROOFING NAILS

④ 12'-0" GRAVEL STOP SECTIONS

② CONTINUOUS CLEAT

③ SPLICE PLATE

FASTEN GRAVEL STOP AND CONTINUOUS CLEAT WITH PROVIDED NAILS

⑤ 3/8" SPACE AT EACH JOINT

STEP ⑤ CONTINUE BY INSTALLING GRAVEL STOP SECTIONS ALLOWING A 3/8" SPACE BETWEEN SECTIONS AS SHOWN. FIELD CUT AS NECESSARY.

CAUTION : REMOVE PROTECTIVE FILM IMMEDIATELY AFTER INSTALLATION. INSTALLERS SHALL WEAR PROTECTIVE EYEWEAR TO PREVENT INJURY.



PHONE: 800-922-8800
EMAIL: PGUARD@SIPLAST.COM

DATE: 04/02/19
DRN BY: ZS
CKD BY: SAK

SHT.# ___ OF ___

DWG# 44110-20408

F